

# Harmonics in Metering



Steve Hudson, PE

VP of Hardware Engineering

10737 Lexington Drive  
Knoxville, TN 37932

Phone: (865) 966-5856

[www.powermetrix.com](http://www.powermetrix.com)



# Focus of this Presentation

- Definition and basic theory of harmonics
- What are harmonics as they relate to electric power?
- What are some common sources of harmonics in electronics?
- How do these harmonics affect metering and other equipment in power distribution and measurement?

# Harmonics – What are they?


- Mathematical definition of a harmonic is “a component frequency of the signal that is an integer multiple of the fundamental frequency.”
- In North America:
  - The fundamental frequency is 60 Hz
  - Integer multiples would be
    - 2<sup>nd</sup> harmonic -  $2 \times 60 = 120$  Hz
    - 3<sup>rd</sup> harmonic –  $3 \times 60 = 180$  Hz
    - 4<sup>th</sup> harmonic –  $4 \times 60 = 240$  Hz

# Harmonics Theory

- Basic Harmonic Theory
  - Harmonics describe disturbances which repeat every cycle for a significant number of cycles
- Engineers use Fourier notation to describe harmonic waveforms


$$V(t) = \sqrt{2} \sum_{n=1}^{\infty} (V_n \sin(n\omega_0 t - \alpha_n))$$

# Harmonics Theory



$$V(t) = \sqrt{2} \sum_{n=1}^{\infty} (V_n \sin(n\omega_0 t - \alpha_n))$$

# Harmonics Theory



Even a square wave can be represented as a series of harmonics.

# Harmonics in Power

- Repetitive contamination of the voltage or current waveform
- Generated by non-linear loads. Voltage harmonics are a reflection of the non-linear load on a distribution system with finite impedance
- Produce a variety of infrastructural problems
- Generate system losses
- Can result in metering errors and disputes

# Harmonics – what aren't they?

- Sags, dips, swells
- Transient voltages
- Frequency variations



These are all non-periodic kinds of power quality issues. Harmonics **MUST** be periodic, meaning they occur at a given interval.



# Focus on Harmonics



- Where do harmonics come from?
  - Non-linear loads at the customer's site
  - Coupling from loads at other sites sharing the distribution system
    - One customer's harmonic current load is converted into voltage harmonics at other customer's sites by the impedance of the system

# Linear Load – Resistive





Resistors are measured in Ohms. When an AC voltage is applied to a resistor, the current is in degrees. A resistive load is considered a “linear” load because when the voltage is sinusoidal the current is sinusoidal.

# Linear Load – Inductive





Inductors are measured in Henries. When an AC voltage is applied to an inductor, the current is 90 degrees out of phase. We say the current “lags” the voltage. A inductive load is considered a “linear” load because when the voltage is sinusoidal the current is sinusoidal.

# Linear Load – Capacitive



Capacitors are measured in Farads. When an AC voltage is applied to a capacitor, the current is 90 degrees out of phase. We say the current “leads” the voltage. A capacitive load is considered a “linear” load because when the voltage is sinusoidal the current is sinusoidal.

# Non-Linear Load – Switching Power Supply



An AC-DC switching power supply is an example of a non-linear load. The circuit uses a diode and switch (normally a transistor or relay) which produces a non-sinusoidal effect on the current as seen in the waveform above.

# Total Harmonic Distortion (THD)

THD is a measurement of the ratio of the sum of the harmonic power to the power of the fundamental frequency.

$$\text{THD} := \frac{\sqrt{\sum_{n=2}^4 (V_n)^2}}{V_1}$$

This is an equation for a waveform with 3 harmonics.

$V_1$  is the fundamental (60Hz)

$V_2$  is the 2<sup>nd</sup> harmonic (120Hz)

$V_3$  is the 3<sup>rd</sup> harmonic (180Hz)

$V_4$  is the 4<sup>th</sup> fundamental (240Hz)

# Total Harmonic Distortion (THD)

## EXAMPLES

Fundamental signal (60 Hz) is 10A

2<sup>nd</sup> harmonic (120 Hz) is 0.3A

3<sup>rd</sup> harmonic (180 Hz) is 0.2A

4<sup>th</sup> harmonic (240 Hz) is 0.1A

THD = 3.7%

Fundamental signal (60 Hz) is 12A

2<sup>nd</sup> harmonic (120 Hz) is 10A

3<sup>rd</sup> harmonic (180 Hz) is 3A

4<sup>th</sup> harmonic (240 Hz) is 1.5A

THD = 87.9%

It is possible for THD to be greater than 100%, meaning that the signal has more harmonic energy than fundamental energy!

# Past Harmonic Sources

SOURCE	TYPE	LEVEL
<b>Transformer</b> <ul style="list-style-type: none"> <li>▪ Saturation</li> <li>▪ Energization</li> </ul>	<b>Current Harmonics</b> <b>3,5,7... &amp; 2,4...</b>	<b>1 to 85%</b>
<b>Arc Furnace Welders</b>	<b>Voltage Harmonics</b> <b>5 &amp; 7</b>	<b>2.5 to 8%</b>
<b>Line Commutated Converters</b>	<b>Volt. &amp; Cur. Harmonics</b> <b><math>H = np \pm 1</math></b>	<b>10 to 30%</b>
<b>Static VAR Compensators</b>	<b>Current Harmonics</b> <b><math>H = np \pm 1</math></b>	<b>2 to 4%</b>
<b>Saturable Reactors</b>	<b>Current Harmonics</b> <b>3,5,7...</b>	<b>1 to 8%</b>



# New Harmonic Sources

SOURCE	TYPE	LEVEL
Fluorescent Lighting	Current Harmonics 3,5,7... up to > 49	> 400%
Electronic Power Supplies Especially Computers	Current Harmonics 3,5,7... up to > 25	>100%

# Are Newer Light Bulbs “green”?


- Big push now underway to move to “green” light bulbs such as CCFL and LED in place of incandescent
- CCFL’s and LED’s consume lower W and VA overall for a comparable amount of light

**EXCEPT.....**

- They generate VARs and a high level of harmonics!




# Green 60W Incandescent Bulb

Waveform Analysis BETA TEST - p8.84M/v6.69M/c#336.98K - Selected Site: None



Record Restart

Harmonic Analysis BETA TEST - p8.54M/v6.88M/c#337.02K - Selected Site: None




Measurement: Last TestSec V/Sec I, Instantaneous

Restart

Active Power = 41W  
Reactive Power = <1 VAR  
Apparent Power = 41VA  
Current THD = 1.5%

# 60W Equivalent CCFL Bulb




Waveform Analysis BETA TEST - p9.03M/v6.88M/c#336.98K - Selected Site: None



Measurement: Last TestSec V/Sec I, Instantaneous

Record Restart

Harmonic Analysis BETA TEST - p8.24M/v6.63M/c#337.03K - Selected Site: None




Measurement: Last TestSec V/Sec I, Instantaneous

Restart

Active Power = 14 W  
Reactive Power = 6 VAR  
Apparent Power = 16 VA  
Current THD = 88%

# 60W Equivalent LED Bulb




Waveform Analysis BETA TEST - p8.96M/v6.81M/c #336.98K - Selected Site: None



Measurement: Last TestSec V/Sec I, Instantaneous

Record Restart

Harmonic Analysis BETA TEST - p8.78M/v6.63M/c #336.98K - Selected Site: None




Measurement: Last TestSec V/Sec I, Instantaneous

Restart

Active Power = 11 W  
Reactive Power = 4 VAR  
Apparent Power = 12 VA  
Current THD = 111%

# Laptop Computer Power Supply




Waveform Analysis BETA TEST - p8.84M/v6.69M/c #336.98K - Selected Site: None



Measurement: Last TestSec V/Sec I, Instantaneous

Record Restart

Harmonic Analysis BETA TEST - p8.18M/v6.56M/c #337.07K - Selected Site: None



Measurement: Last TestSec V/Sec I, Instantaneous

Restart

Active Power = 35 W  
Reactive Power = 6 VAR  
Apparent Power = 37 VA  
Current THD = 144%

# Harmonic Theory

## An Alternate Approach


- Harmonics can be grouped into “sequences” which help us understand their effects.

Name	F	2 <sup>nd</sup>	3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>	6 <sup>th</sup>	7 <sup>th</sup>	8 <sup>th</sup>	9 <sup>th</sup>
Freq	60	120	180	240	300	360	420	480	540
Seq	+	-	0	+	-	0	+	-	0

# Harmonic Theory

## An Alternate Approach

Name	F	2 <sup>nd</sup>	3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>	6 <sup>th</sup>	7 <sup>th</sup>	8 <sup>th</sup>	9 <sup>th</sup>
Freq	60	120	180	240	300	360	420	480	540
Seq	+	-	0	+	-	0	+	-	0



### Positive (+)


- If fundamental rotation is ABC then positive (+) sequence harmonics have ABC rotation



# Harmonic Theory

## An Alternate Approach

Name	F	2 <sup>nd</sup>	3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>	6 <sup>th</sup>	7 <sup>th</sup>	8 <sup>th</sup>	9 <sup>th</sup>
Freq	60	120	180	240	300	360	420	480	540
Seq	+	-	0	+	-	0	+	-	0




### Negative (-)

- If fundamental rotation is ABC then negative (-) sequence harmonics have CBA rotation

# Harmonic Theory

## An Alternate Approach

Name	F	2 <sup>nd</sup>	3 <sup>rd</sup>	4 <sup>th</sup>	5 <sup>th</sup>	6 <sup>th</sup>	7 <sup>th</sup>	8 <sup>th</sup>	9 <sup>th</sup>
Freq	60	120	180	240	300	360	420	480	540
Seq	+	-	0	+	-	0	+	-	0



### ZERO (0)

- If fundamental rotation is ABC then zero (0) sequence harmonics have NO rotation

# Harmonic Theory

## An Alternate Approach

- Positive (+)
  - Heating of conductors and transformers
- Negative (-)
  - Heating of conductors and transformers
  - Tries to make motors run backwards
- Zero (0)
  - Results in neutral currents which can be larger than phase currents


# How do harmonics affect metering?

- Mechanical meters will not register harmonics well – 80% error at higher harmonics
- Solid state meters can measure harmonics well depending on the sampling rate and VAR calculation used
- CTs and PTs can only pass a limited range of harmonics

# Harmonics & Metering Accuracy

- Primarily affect the calculation of VA, VAR and Power Factor
  - No ANSI standard for these calculations at this time
  - Different manufacturers use different methods and definitions.
  - Most manufacturers allow the user to make several choices for each
  - Differences of over 50 percent in answers can occur in high harmonic situations


# Harmonics & Metering Accuracy




**Waveform #1 - 90 Degree Phased Fired Waveform  
Typical for a light dimmer set to 50%**

# Harmonics & Metering Accuracy

Voltage




Current




**Waveform #2 - Quadriform Waveform  
Switched Load Device**

# Harmonics & Metering Accuracy

Voltage



Current




**Waveform #3 - Peaked Waveform  
Switching Power Supply**




# Harmonics & Metering Accuracy

Voltage




Current




**Waveform #4 - Pulse Waveform  
Switching Power Supply**

# Harmonics & Metering Accuracy

Voltage




Current




**Waveform #5 – Multiple Zero Crossing Current Waveform**

# Harmonics & Metering Accuracy

Voltage



Current



**Waveform #6 – Multiple Zero Crossing Voltage  
Waveform**

# Harmonic Compensation

- Harmonics can be compensated for at the customer's facility
- Solution must be tailored to the problem
- Examples of solutions:
  - Active Filter – mirror image of harmonic
  - Tuned Filter – effective but expensive
  - Zig zag transformer reduces 3<sup>rd</sup> harmonics in neutral
- There is no “one size fits all” solution

# IEEE Power Quality Standards

- SCC-22 Power Quality Standards Coordinating Committee
- 1159: Monitoring Electric Power Quality
  - 1159.1: Guide for Recorder and Data Acquisition Requirements
  - 1159.2: Power Quality Event Characterization
  - 1159.3: Data File Format for Power Quality Data Interchange
- P1564: Voltage Sag Indices
- 1346: Power System Compatibility with Process Equipment
- P1100: Power and Grounding Electronic Equipment
- 1433: Power Quality Definitions
- P1453: Voltage Flicker
- 519: Harmonic Control in Electrical Power Equipment
- P519A: Guide for Applying Harmonic Limits on Power Systems

# IEC Power Quality Standards

- 61000-1-X Definitions and methodology
- 61000-2-X Environment
- 61000-3-X Limits
- 61000-4-X Test and measurements
- 61000-5-X Installation and mitigation
- 61000-6-X Generic immunity and emissions standards
- Working Groups and Committees
  - SC77A Low Frequency EMC Phenomena
  - TC77/WG1 Terminology
  - SC77A/WG1 Harmonics and other low frequency disturbances
  - SC77A/WG6 Low frequency Immunity Tests
  - SC77A/WG2 Voltage fluctuations and other low frequency disturbances
  - SC77A/WG9 Power Quality measurement methods